

KSI Loudspeaker Installation

INSTALLATION OF MODELS C, CS & CSHP



Remove two ceiling tiles.



Place the grille into the first opening.



Screw on the supplied hooks.



Slide the loudspeaker onto the grille.



Wire the loudspeaker and connect to the structure above. See Note.



Replace the second tile.

INSTALLATION OF MODELS CSD & CSDHP



Remove two ceiling tiles.



Screw on the supplied hooks.



Slide the loudspeaker through the opening. Make sure that it fits flush.



Wire the loudspeaker and connect to the structure above. See Note.



Snap on the grille and replace the second tile.

INSTALLATION OF RETROFIT MODELS WITH KSI CONTINUOUS COMPRESSION CLAMPS



Tape the template to the desired area. Cut the drywall for the selected model.



Fish the wire and add fiberglass.



Wire the loudspeaker. See Note.



Slip the loudspeaker into the opening.




Tighten the clamps.




Snap on the grille.

INSTALLATION OF PRECONSTRUCTION MODELS WITH SEALED BACK BOXES




Mount the backbox between 2 studs. 16" on center.



Use a metal box and make the wire connection to the backbox. You can drywall over the backbox.



Cut the opening in the drywall to expose the backbox.



Holding the baffle, use the wire nuts to connect the baffle to the internal wires.



Screw the baffle into the backbox.



Snap on the grille.

NOTE: You must make certain that electrical connections meet all local codes. Make absolutely sure that the loudspeaker is securely attached to the grid and structure above.